





INSTRUCTIONS TO DOWNLOAD TENDERCARD ON OMNI 37xx/Vx TERMINALS

Step	Terminal Display	Action
1	Idle prompt	Press F2 and the F4 buttons at the same time
2	SYSTEM MODE ENTRY PASSWORD	Type 1 ALPHA ALPHA 66831 and Press  (Enter)
3	SYS MODE MENU 1	Press Down Arrow Button []
4	SYS MODE MENU 2	Press Down Arrow Button []
5	SYS MODE MENU 2	Press F2 for Download
6	SYS MODE FILE FILE GROUP _1	Press 5 , 
7	SYS MODE FILE GROUP 5 PASSWORD -----	Type 1 ALPHA ALPHA 66831 and Press  (Enter). <i>Note: If this password does not work, contact credit card processor for password for Group 5.</i>
8	SYS MODE DOWNLOAD G 5	Press F3 for Full
9	SYS MODE DOWNLOAD G 5	Press F2 for Modem.
10	*ZP HOST PHONE NUMBER -----	Enter 18004307995 , Press  (Enter a PBX code, if needed, before the ph#.)
11	*ZT TERMINAL ID -----	Type the <i>Download Terminal ID</i> provided by TenderCard (usually merchant's TenderCard ID.) Press 
12	*ZA APPLICATION -----	Enter TCARD (Use ALPHA key to change numbers to letters), Press 
13	SYS MODE DOWNLOAD G 5 *ZA=TCARD *ZP=18004307995 *ZT=XXXXXXX (Terminal ID entered above)	Review parameters – if correct, Press F4 for START . If not, press F3 for EDIT and correct the parameters. (Some terminals may not have this step).
14	SYS MODE DOWNLOAD G 5 ----- DOWNLOADING NOW	As the download is progressing, dashes will turn into asterisks (one asterisk for each 10% completed) **----- . When all ten asterisks display, the download is complete.
15	SYS MODE DOWNLOAD G 5 DOWNLOAD DONE DOWNLOADING NOW	Press  . Terminal will restart, unzip files, start VMAC, and then the main menu will display the credit card application, TENDERCARD, and any other applications in the terminal.